Specification

| Product Name | Wearable Bluetooth Speaker & White Noise Device |
|-------------------------|--|
| Product Model | UL-SPE-11045 |
| Connectivity | Bluetooth v5.0 |
| Key Feature | Wireless, 4-ways Wearable, White Noise, IPX6 Waterproof, and Pocket Size |
| Charging Capacity | 500 mAh |
| Charging Time | 1.5 hours |
| Playtime Standby Time | 9.5 hours 18 hours |
| Compatible Devices | Laptop, Smartphone, Tablet |
| Included Components | Speaker, Detachable Wristband, Clothing Clip, Hang Clip, Type-C USB Cable, User Manual |
| Product Weight | 60 g |
| Product Dimension | 63 (D) x 290 (W) x 33 (H) mm |
| | PAGE 4 |



WEARABLE BLUETOOTH SPEAKER & WHITE NOISE DEVICE



www.ultrapopp.com | support@ultrapopp.com

How to Use



volume - / previous track button

Step 1. Long Press

Turn the device on or off.

Step 2. Quick Press

Pause and resume.

Step 3. Double Press —

Switch between Bluetooth and White Noise mode.

Step 4: Double Press

Set White Noise playtime to 30 mins (default), 60 mins, or continuous.

Step 5: Long Press — or —

Next or previous track.

Step 6: Short Press — or —

Adjust volume up or down.

Features



Wireless Bluetooth compatible with most safe for outdoor devices





Long Playtime
plays up to 9.5 hours




HD Sound better sound performance



4-ways Wearable wristband, clothing clip, hang clip, hang strap



White Noise & Lullaby 16 white noise tracks 4 Iullaby music



PAGE 3 PAGE 2